

V slot - Eccentric Spacer

Eccentric spacers are used to tighten the V-wheel in to the V-track. They are mounted on V-plates, where they fasten the wheel to the track.



Eccentric spacers are used to tighten the V-wheel in to the V-track. They are mounted on V-plates with M5 bolts, where they fasten the wheel to the track. This means that they are one of the most important components in increasing precision and reducing play.

Dimensions are mounted height x inner diameter. Total height is 8.5mm.

Buy online at:

www.matronics.eu/V500434



6.35x5.3mm (10mm key)
SKU V500434



6.0x5.3mm (10mm key)
SKU V500441



6.0x5.3mm (8mm key)
SKU V500442

Product pictures

